

Typical ProLine Drain Installation Details

Note: Set all Quick Slope and Flat Panel on structurally sound, flat sub-floor with fast-setting, self-curing thinset.
Set the drain body level. Do not follow sub-floor if it is out of level.
Do not grout in strainer. Strainer must remain removable for maintenance.
Use proper reinforcing framing techniques when recessing drain into wood sub-floor. See Quick Drain details.

