

Typical ProLine Drain Installation Details

Note: Set the drain body level. Do not follow sub-floor if it is out of level.
Do not grout in strainer. Strainer must remain removable for maintenance.

